

# Vision TECHCONNECT TC2-CTL3 to RS-232 Audio Visual Controller

Vision Techconnect TC2-CTL3. How to wire connect your vision TC2-CTL3 Controller for RS-232 devices.

RS-232 - Pin 5: Ground - Pin 2: RX (Receive) pin 3: TX (Transmit)

